

BALANCES À CORDE

Série 747 «Drop-In»

Tableaux de charges

Numéro de balance	Plage de poids	Numéro de balance	Plage de poids	Numéro de balance	Plage de poids	Numéro de balance	Plage de poids
30A	8 - 13	34A	11 - 16	38A	11 - 16	42A	11 - 16
30B	13 - 19	34B	16 - 22	38B	16 - 22	42B	16 - 22
30C	19 - 24	34C	22 - 27	38C	22 - 27	42C	22 - 27
30D	24 - 29	34D	27 - 32	38D	27 - 32	42D	27 - 32
30E	29 - 33	34E	32 - 34	38E	32 - 34	42E	32 - 34
30F	33 - 37	34F	34 - 37	38F	34 - 37	42F	34 - 37
30G	37 - 40	34G	37 - 40	38G	37 - 40	42G	37 - 40
30H	40 - 43	34H	40 - 43	38H	40 - 43	42H	40 - 43
		34I	43 - 45	38I	43 - 45	42I	43 - 45
		34J U/L	45 - 48/ LT24	38J U/L	45 - 48/ LT22	42J U/L	45 - 48/ LT28
		34K U/L	48 - 51/ LT21	38K U/L	48 - 51/ LT22	42K U/L	48 - 51/ LT24
		34L U/L	51 - 54/ LT22	38L U/L	51 - 54/ LT24	42L U/L	51 - 54/ LT28
31A	8 - 13	35A	11 - 16	39A	11 - 16	43A	11 - 16
31B	13 - 19	35B	16 - 22	39B	16 - 22	43B	16 - 22
31C	19 - 24	35C	22 - 27	39C	22 - 27	43C	22 - 27
31D	24 - 29	35D	27 - 32	39D	27 - 32	43D	27 - 32
31E	29 - 33	35E	32 - 34	39E	32 - 34	43E	32 - 34
31F	33 - 37	35F	34 - 37	39F	34 - 37	43F	34 - 37
31G	37 - 40	35G	37 - 40	39G	37 - 40	43G	37 - 40
31H	40 - 43	35H	40 - 43	39H	40 - 43	43H	40 - 43
		35I	43 - 45	39I	43 - 45	43I	43 - 45
		35J U/L	45 - 48/ LT19	39J U/L	45 - 48/ LT26	43J U/L	45 - 48/ LT22
		35K U/L	48 - 51/ LT18	39K U/L	48 - 51/ LT22	43K U/L	48 - 51/ LT26
		35L U/L	51 - 54/ LT23	39L U/L	51 - 54/ LT24	43L U/L	51 - 54/ LT28
32A	8 - 14	36A	11 - 16	40A	11 - 16	44A	11 - 16
32B	14 - 20	36B	16 - 22	40B	16 - 22	44B	16 - 22
32C	20 - 25	36C	22 - 27	40C	22 - 27	44C	22 - 27
32D	25 - 30	36D	27 - 32	40D	27 - 32	44D	27 - 32
32E	30 - 34	36E	32 - 34	40E	32 - 34	44E	32 - 34
32F	34 - 37	36F	34 - 37	40F	34 - 37	44F	34 - 37
32G	37 - 40	36G	37 - 40	40G	37 - 40	44G	37 - 40
32H	40 - 43	36H	40 - 43	40H	40 - 43	44H	40 - 43
32I U/L	43 - 45/ LT20	36I	43 - 45	40I	43 - 45	44I	43 - 45
32J U/L	45 - 48/ LT16	36J U/L	45 - 48/ LT24	40J U/L	45 - 48/ LT30	44J U/L	45 - 48/ LT26
32K U/L	48 - 51/ LT20	36K U/L	48 - 51/ LT20	40K U/L	48 - 51/ LT26	44K U/L	48 - 51/ LT22
32L U/L	51 - 54/ LT16	36L U/L	51 - 54/ LT22	40L U/L	51 - 54/ LT26	44L U/L	51 - 54/ LT28
33A	8 - 14	37A	11 - 16	41A	11 - 16		
33B	14 - 20	37B	16 - 22	41B	16 - 22		
33C	20 - 25	37C	22 - 27	41C	22 - 27		
33D	25 - 30	37D	27 - 32	41D	27 - 32		
33E	30 - 34	37E	32 - 34	41E	32 - 34		
33F	34 - 37	37F	34 - 37	41F	34 - 37		
33G	37 - 40	37G	37 - 40	41G	37 - 40		
33H	40 - 43	37H	40 - 43	41H	40 - 43		
33I	43 - 45	37I	43 - 45	41I	43 - 45		
33J U/L	45 - 48/ LT21	37J U/L	45 - 48/ LT26	41J U/L	45 - 48/ LT24		
33K U/L	48 - 51/ LT18	37K U/L	48 - 51/ LT24	41K U/L	48 - 51/ LT20		
		37L U/L	51 - 54/ LT24	41L U/L	51 - 54/ LT26		